

SERVICE MANUAL


UA-140/160R


STEREO AMPLIFIER




BLOCK DIAGRAM (FOR/UA-160R)








SCHEMATIC DIAGRAM (FOR UA-160R)





WIRING DIAGRAM

